

Quick start guide

Seven easy steps to install



PLANNING STATION

How to install Voyager PLANNING STATION

Important

You will require user permissions on your computer to ensure successful installation of any required pre-requisite component applications. Please refer to the installation troubleshooting guide. You may need to contact your IT department to grant permission to install Voyager PLANNING STATION as an Administrator.

1. Insert USB

Insert the Voyager PLANNING STATION USB into your PC. If the USB window does not display automatically, browse to the drive in Windows Explorer and double click on VPS_Setup.exe.

2. Launch Voyager PLANNING STATION setup

Select Install Voyager PLANNING STATION from the list of options.

3. System check performed

Your PC will be checked for any required pre-requisite component applications to install. You may be prompted to confirm you wish to proceed. Accept and continue.

4. Check the terms & conditions

Read and accept the terms and conditions by selecting the check box.

5. Install Voyager PLANNING STATION


Click **Install** to begin installation. Voyager PLANNING STATION and all required data will be installed and configured. Once complete, click **Launch** to open Voyager PLANNING STATION setup configuration.

Note: You may be prompted to confirm you wish to proceed. Accept and continue.

6. Voyager PLANNING STATION setup and configuration settings.

You now need to check and update your Voyager PLANNING STATION configuration and data. Import your LICENCE_KEY.txt file received via email.

If you have not received a LICENCE_KEY please contact:
customerservices@voyagerww.com.



Click the **Import button** next to the Voyager PLANNING STATION Licence missing or expired alert. Browse to and select your LICENCE_KEY.TXT and click Open.

Set your preferred update method for web updates or email updates.

- **Web:** Updates are synchronised automatically via a connected web service.
- **Email:** Updates are exchanged via email with the option to set maximum download size.

Helpful hint:

We strongly recommend the Voyager CLOUD web update method to give you the best user experience.

Test your web/FTP connection. If the connection fails, please refer to Installation troubleshooting and contact your IT department to configure access to the web and FTP services listed on screen and in the guide.

Download or import a Voyager PLANNING STATION update to update your vessel data.

Send a Sync update to synchronise your Voyager PLANNING STATION installation with the Voyager server.

Note: For email update method, send the Sync update to VPSSync@voyagerww.com.

Click **Initialise** to update your NTM correction log to the latest week if required.

7. Launch Voyager PLANNING STATION

Congratulations! Your installation is complete. You can launch Voyager PLANNING STATION now.

